

# PUNTO eMANUAL

EEFD

Title	Page
Chart index .....	1 ➡
Chart 1 .....	3 ➡
Chart 2 .....	9 ➡
Chart 3 .....	15 ➡
Chart 4 .....	21 ➡
Chart 5 .....	27 ➡
Chart 6 .....	32 ➡
Chart 7 .....	38 ➡
Chart 8 .....	44 ➡
Chart 9 .....	49 ➡
Chart 10 .....	54 ➡
Chart 11 .....	60 ➡
Chart 12 .....	65 ➡
Chart 13 .....	71 ➡
Chart 14 .....	76 ➡
Chart 15 .....	81 ➡

Chart No.	Functions involved
<b>Chart 1</b>	<b>Version: 1108 SPI - 1242 SPI</b> Starting - Ignition and electronic injection I.A.W. 6F.SB - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter
<b>Chart 2</b>	<b>Version: 1242 MPI</b> Starting - Ignition and electronic injection I.A.W. 8F.5T - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter
<b>Chart 3</b>	<b>Version: 1372 MPI turbo</b> Starting - Motronic electronic ignition and injection (Bosch) - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system fail- ure warning light - Rev counter
<b>Chart 4</b>	<b>Version: 1698 TD</b> Starting - Pre-heating system and warning light - Recharging and warning light - Insufficient engine oil pressure warning light - Maximum turbocharging pres- sure warning light - Rev counter
<b>Chart 5</b>	Electrically operated sun roof - Headlamp alignment cor- recter
<b>Chart 6</b>	Parking lights and warning lamp - Dipped beam head- lamps - Main beam headlamps and warning light - Headlamp flasher - Number plate lights
<b>Chart 7</b>	Windscreen wiper - Rearscreen wash/wipe - Wind- screen and rear window washer pump - Electric horns - Heated rear windscreen and warning light
<b>Chart 8</b>	Fog lights and warning light - Rear fog lamps and warn- ing light - Handbrake warning light



# Fault diagnosis


Punto

Accompaniment to illustration table


55D.

Chart No.	Functions involved
<b>Chart 9</b>	Engine cooling - Car interior ventilation - Water temperature gauge - Cigar lighter
<b>Chart 10</b>	Anti-lock brakes (A.B.S. 2SH) and failure warning light
<b>Chart 11</b>	Electric front windows
<b>Chart 12</b>	Central locking - Warning light signalling doors ajar
<b>Chart 13</b>	Control-system device - Direction indicators and warning light - Hazard warning lights and warning light - Reversing lights - Braking lights and warning light (check)
<b>Chart 14</b>	AIR-BAG device and failure warning light
<b>Chart 15</b>	Preparation for radio - Courtesy light - Ideogram lights


## Chart 1



P3M201 N03



P3M201 N01



P3M201 N02

### GENERAL DESCRIPTION

#### Ignition:

All the systems and all the electrical equipment are supplied by the battery at a voltage of 12V.

The cables through which the battery voltage is distributed to the various consumers are represented in the wiring diagrams for the various function and various systems. The Weber--Marelli 6F.SB model which is fitted on the 1108 SPI and 1242 SPI versions of the PUNTO belong to the category of integrated systems: static advance digital electronic ignition and single point intermittent type petrol injection (i.e. with only one injector).

Some circuits are constantly supplied, even with the vehicle stationary and the ignition switched off as they are connected directly to the battery.

Other circuits are supplied when the ignition switch is turned to the various positions.

#### Starting and recharging:

The starting and recharging circuit is made up of the battery, the starter motor and the alternator.

The battery (12V) is the sealed type which is maintenance free. The starter motor consists of a direct current motor supplied by the battery and an operation and engagement solenoid.

When the ignition is switched on the voltage coming from the battery supplies the motor windings, creating electro-magnetic forces which cause the rotation of the motor pinion: at the same time the solenoid is energized which operates the pinion engagement mechanism in the flywheel ring gear, thereby causing the rotation of the crankshaft.

The alternator recharges the battery whilst the engine is rotating normally: the alternator shaft, which is rotated directly by the crankshaft through a belt, "cuts" the magnetic field generated by the stator winding producing an alternating current; this is transformed into a direct current by a diode rectifier bridge and is sent to recharge the battery.

A voltage regulator incorporated in the alternator allows the current supply to be kept at a constant voltage (around 12V) for all engine speed and load condition variations.

### FUNCTIONAL DESCRIPTION

The supply comes from the battery (53), from where there are numerous cables which directly supply several systems including the connector block (36), which is connected directly to the ignition switch (3).

The alternator (139) is connected directly to the starter motor (140) in order to allow the recharging of the battery.

When the ignition key (3) is inserted and turned to the first stage this is the ON position supplying numerous circuits which are defined as "controlled by the ignition key".

The second position is starting up where the starter motor (140) is directly supplied with the current no longer reaching all those circuits which absorb directly thereby ensuring a maximum flow to the actual engine.

In the last analysis we shall assess the "Park" position where the side lights are supplied with the key in, which is possible by turning the key in the opposite direction (pressing the special button on the ignition switch).







When the ignition key (3) is in the "Starting" position, the starter motor (140) solenoid winding (pin 50) is energized and the supply voltage from the battery (53) reaches the engine (pin 30) and starts it.

The direct current generated by the alternator (139) is sent to the battery, passing through the starter motor.

When the alternator does not rotate, therefore the battery is not being recharged, a special signal is sent to the Instrument panel (14) to light up the battery recharging warning light (X).







## 55D.

Location of components for starting - Ignition - Recharging




P3M208N02

### Location of components for starting - Ignition - Recharging



P3M203N02 P3M203N01






P3M204N02 P3M204N01

**Wiring for starting - Ignition and electronic injection I.A.W. 6F.SB - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter**

### Key for components







- |  |   |
|--|---|
| 3 Ignition switch  | 124 Multiple relay  |
| 4 Steering column switch unit  | 125 Heated Lambda sensor                                  |
| 7 Junction unit  | 126 Potentiometer on throttle valve                       |
| 12 Connection between dashboard cables and front cables                          | 127 Water temperature sensor                              |
| 14 Instrument panel :  | 128 Air temperature sensor                                |
| F Rev counter  | 129 Absolute pressure sensor                              |
| J Insufficient engine oil pressure warning light                                 | 130 Earths on engine                                      |
| Z Injection system failure warning light   | 131 Earth on control unit                                 |
| X Battery recharging warning light   | 132 I.A.W. electronic injection and ignition control unit |
| 16 Left dashboard earth  | 133 Ignition coil unit                                    |
| 33 Connection for front cables   | 134 Spark plugs   |
| 36 Connector block   | 135 Stepping actuator                                     |
| 47 Fuel level gauge / Electric fuel pump   | 136 Canister solenoid valve                               |
| 52 Right rear earth  | 137 Rpm and T.D.C. sensor.                                |
| 53 Battery   | 138 Diagnostic socket for injection system                |
| 54 Earth for battery   | 139 Alternator  |
| 86 Switch signalling insufficient engine oil pressure                            | 140 Starter motor   |
| 91 Fuse and relay control box for air conditioning :                             | 141 Injector  |
| E Compressor coupling relay  | 159 Switch for deactivating electric fuel pump            |
| 95 Air conditioning system electronic control unit                               | 162 Connection for air conditioner unit cables            |
| 122 5A protective fuse for injection system                                      | 166 Anti-theft device electronic control unit             |
| 123 20A protective fuse for injection electric pump, Lambda sensor and injectors | N.D. Connectors   |

Starting - Ignition and electronic injection I.A.W 6F.SB - Recharging and warning light - Insufficient engine oil pressure  
warning light - Injection system failure warning light - Rev counter




### 55D.

Location of components for starting - Ignition - Recharging




P3M206N02 P3M206N01


## Chart 2



P3M201 N03



P3M201 N01



P3M201 N02

### GENERAL DESCRIPTION

#### Ignition:

All the systems and all the electrical equipment are supplied by the battery at a voltage of 12V.

The cables through which the battery voltage is distributed to the various consumers are represented in the wiring diagrams for the various functions and various systems. The I.A.W. (Weber injecton/ignition) 8F.5T model belongs to the category of static advance digital electronic ignition and multiple type, non timed petrol injection systems i.e. where all the injectors are connected in parallel (FULL-GROUP) and inject half the quantity of fuel required to form the air/petrol mixture at the same time for each revolution of the crankshaft.

#### Starting and recharging:

The starting and recharging circuit is made up of the battery, the starter motor and the alternator.

The battery (12V) is the sealed type which is maintenance-free. The starter motor consists of a direct current motor supplied by the battery and an operation and engagement solenoid.

When the ignition is switched on the voltage coming from the battery supplies the motor windings, creating electro-magnetic forces which cause the rotation of the motor pinion: at the same time the solenoid is energized which operates the pinion engagement mechanism in the flywheel ring gear, thereby causing the rotation of the crankshaft.

The alternator recharges the battery whilst the engine is rotating normally: the alternator shaft, which is rotated directly by the crankshaft through a belt, "cuts" the magnetic field generated by the stator winding producing an alternating current; this is transformed into a direct current by a diode rectifier bridge and is sent to recharge the battery.

A voltage regulator, incorporated in the alternator, allows the current supply to be kept at a constant voltage (around 12V) for all engine speed and load condition variations.

### FUNCTIONAL DESCRIPTION

The same operating strategies and usage conditions for the components apply equally to many aspects of the MPI I.A.W. 8F.5T system fitted on the 1242 MPI version and the SPI systems fitted on the 1108 and 1242 versions.

The Weber-Marelli I.A.W. 8F.5T injection/ignition system uses an indirect measuring system known as the "SPEED - DENSITY - LAMBDA" type.

In practice, the DENSITY OF THE AIR (pressure and temperature) and the ENGINE SPEED (rpm) are used to measure the amount of air drawn in by the engine.

Air density refers to the density of the air drawn in by the engine and is calculated according to the absolute pressure and temperature, both measured in the inlet manifold.

The quantity for air drawn in by each cylinder, for each engine cycle also depends on the unit capacity and the volumetric efficiency as well as on the density of the intake air.

Volumetric efficiency is the parameter relating to the filling coefficient for the cylinders measured during experimental tests on the engine in all operating conditions and then stored in the electronic control unit (ECU) memory.

Having established the quantity of air drawn in the system has to supply the amount of fuel in accordance with the desired mixture strength.

The information required for determining the air/petrol mixture so that this ratio is kept as close as possible to the stoichiometric ratio is obtained by suitable sensors and is transformed into electrical signals.

The sensors are as follows:







- Heated Lambda sensor (125)
- Potentiometer on the throttle valve (126)
- Water temperature sensor (127)
- Air temperature sensor (128)
- Absolute pressure sensor (129)
- Rpm and T.D.C. sensor. (137)

As far as the starting and recharging are concerned, refer to the 1108 and 1242 SPI versions.









### 55D.

Location of components for starting - Ignition - Recharging




P3M208N02 P3M208N01

### Location of components for starting - Ignition - Recharging



P3M208N02 P3M209N01




P3M210N02 P3M210N01

**Wiring for starting - Ignition and electronic injection I.A.W 8F.5T - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter**

### Key for components

- |  |   |
|--|---|
| 3 Ignition switch  | 124 Multiple relay  |
| 4 Steering column switch unit  | 125 Heated Lambda sensor                                  |
| 7 Junction unit  | 126 Potentiometer on throttle valve                       |
| 12 Connection between dashboard cables and front cables                          | 127 Water temperature sensor                              |
| 14 Instrument panel :  | 128 Air temperature sensor                                |
| F Rev counter  | 129 Absolute pressure sensor                              |
| J Insufficient engine oil pressure warning light                                 | 130 Earth on engine                                       |
| Z Injection system failure warning light   | 131 Earth on control unit                                 |
| X Battery recharging warning light   | 132 I.A.W. electronic injection and ignition control unit |
| 16 Left dashboard earth  | 133 Ignition coil unit                                    |
| 33 Connection for front cables   | 134 Spark plugs   |
| 36 Connector block   | 135 Stepping actuator                                     |
| 47 Fuel level gauge / Electric fuel pump   | 136 Canister solenoid valve                               |
| 52 Right rear earth  | 137 Rpm and T.D.C. sensor.                                |
| 53 Battery   | 138 Diagnostic socket for injection system                |
| 54 Earth for battery   | 139 Alternator  |
| 86 Switch signalling insufficient engine oil pressure                            | 140 Starter motor   |
| 91 Fuse and relay control box for air conditioning :                             | 141 Injectors   |
| E Compressor coupling relay  | 159 Electric fuel pump deactivation switch                |
| 95 Air conditioning system electronic control unit                               | 162 Connection for air conditioner unit cables            |
| 122 5A protective fuse for injection system                                      | 166 Anti-theft device electronic control unit             |
| 123 25A protective fuse for injection electric pump, Lambda sensor and injectors | N.D. Connectors   |

Starting - Ignition and electronic injection I.A.W 8F.5T - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter









\* Variant connection for the version with the anti-theft device




## 55D.

Location of components for starting - Ignition - Recharging




P3M212N02 P3M212N01


## Chart 3



P3M201 N03



P3M201 N01



P3M201 N02

### GENERAL DESCRIPTION

#### Ignition:

All the systems and electrical equipment are supplied by the battery at a voltage of 12V.

The cables through which the battery voltage is distributed to the various consumers are represented in the wiring diagrams for the various function and various systems. The injection/ignition system fitted on the 1372 turbo version of the PUNTO belongs to the generation of integrated fuel injection/ignition systems developed by Bosch.

The injection system is the multiple injector type (Multi-Point), one per engine cylinder, supplied at a low pressure and operated directly by the control unit in a SEQUENTIAL AND TIMED fashion.

This device ensures efficient operation, fuel economy and the maximum possible reduction in harmful exhaust emissions because all Bosch Motronic M2.7 systems conform to the USA '83 pollution control regulations. Lastly, it is important to bear in mind that no adjustments can be made on this type of system to the engine idle speed; the position of the throttle valve sensor and the CO content in the exhaust gases.

#### Starting and recharging:

The starting and recharging circuit is made up of the battery, the starter motor and the alternator.

The battery (12V) is the sealed type which is maintenance-free.

The starter motor consists of a direct current motor supplied by the battery and an operation and engagement solenoid valve.

When the ignition is switched on the voltage coming from the battery supplies the motor windings, creating electro-magnetic forces which cause the rotation of the motor pinion: at the same time the solenoid is energized which operates the pinion engagement mechanism in the flywheel ring gear, thereby causing the rotation of the crankshaft.

The alternator recharges the battery whilst the engine is rotating normally: the alternator shaft, which is rotated directly by the crankshaft through a belt "cuts" the magnetic field generated by the stator winding producing an alternating current; this is transformed into a direct current by a diode rectifier bridge and is sent to recharge the battery.

A voltage regulator, incorporated in the alternator, allows the current supply to be kept at a constant voltage (around 12V) for all engine speed and load condition variations.

### FUNCTIONAL DESCRIPTION

The supply comes from the battery (53), from where there are numerous cables which directly supply several systems including the connector block (36), which is connected directly to the ignition switch (3).

The alternator (139) is connected directly to the starter motor (140) in order to allow the recharging of the battery.

When the ignition key (3) is inserted and turned to the first position this switches the ignition ON supplying numerous circuits which are known as "controlled by the ignition key".

The second position is "STARTING", directly supplying the starter motor and no longer supplying a current to all those circuits which absorb directly, thereby ensuring a maximum flow to the actual engine.

In the last analysis we shall assess the "PARK" position which supplies the side lights with the ignition key in, which is possible by turning the key in the opposite direction (pressing the special button on the ignition switch).







The ignition system is made up of:

- A. A power module (188) outside the control unit which passes a current through the ignition coil (133) primary circuit in order to energize it completely and then instantly cut off the flow of this current to create a very high tension in the secondary winding and cause a spark at the spark plug.
- B. An ignition coil (133) with four high tension terminals, made up of two primary windings (supplied by the battery voltage) and two secondary ones (high tension) directly connected to the spark plugs for the cylinders.

The information required by the control unit (119) to operate the power module (188), is transmitted via electrical signals emitted by the following two sensors:

- a) RPM AND TDC SENSOR (137) which produces a single-phase alternating signal with the frequency indicating the engine speed.
- b) AIR FLOW METER (202) which, on the basis of the quantity of air drawn in by the engine, transforms this value into an electrical signal, sending it to the control unit (119).







#### Location of components for starting - Ignition - Recharging



P3M214N02 P3M214N01




#### Location of components for starting - Ignition - Recharging



P3M215N02 P3M215N01






P3M216N02 P3M216N01

**Wiring for starting - Motronic electronic ignition and injection (Bosch) - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter**

### Key for components

- |   |   |
|---|---|
| 3 Ignition switch                                       | 136 Canister solenoid valve                     |
| 4 Steering column switch unit                           | 137 Rpm and T.D.C. sensor.                      |
| 7 Junction unit   | 138 Diagnostic socket for injection system      |
| 12 Connection for dashboard cables with front cables    | 139 Alternator                                  |
| 14 Instrument panel :                                   | 140 Starter motor                               |
| F Rev counter   | 141 Injectors                                   |
| J Insufficient engine oil pressure warning light        | 159 Electric pump deactivating switch           |
| Z Injection system failure warning light                | 166 Anti-theft device electronic control unit   |
| X Battery recharging warning light                      | 188 Power module                                |
| 16 Left dashboard earth                                 | 189 Pierburg solenoid valve (Waste-Gate)        |
| 22 Impulse generator for speedometer signal             | 190 Idle adjustment actuator                    |
| 33 Connection for front cables                          | 191 Injector cooling fan switch                 |
| 36 Connector block                                      | 192 Connection for front cables                 |
| 39 Left front earth                                     | 193 Injection system relay feed                 |
| 47 Fuel level gauge / Electric fuel pump                | 194 Relay for Lambda sensor, electric fuel pump |
| 52 Right rear earth                                     | 195 10A protective fuse for electric fuel pump  |
| 53 Battery  | 196 10A protective fuse for Lambda sensor       |
| 54 Earth for battery                                    | 197 Timing sensor                               |
| 86 Switch signalling insufficient engine oil pressure   | 198 Detonation sensor                           |
| 119 Fuel injection control unit BOSCH (1372 Turbo i.e.) | 199 Distance correcter                          |
| 122 10A protective fuse for injection system            | 200 Earth signal                                |
| 125 Heated Lambda sensor                                | 201 Power earth                                 |
| 126 Potentiometer on throttle valve                     | 202 Air flow meter                              |
| 127 Water temperature sensor                            | 203 Injector cooling fan                        |
| 128 Air temperature sensor                              | 204 20A protective fuse for injector cooling    |
| 130 Earth on engine                                     | N.D. Connectors                                 |
| 133 Ignition coil unit                                  |   |
| 134 Spark plugs   |   |






Starting - Motronic electronic ignition and injection (Bosch) - Recharging and warning light - Insufficient engine oil pressure warning light - Injection system failure warning light - Rev counter



\* Variant connections for versions with anti-theft device


### 55D.

Location of components for starting - Ignition - Recharging




P3M218N02 P3M218N01


## Chart 4



P3M219N01



P3M201N01



P3M201N02

### GENERAL DESCRIPTION

#### Ignition:

All the systems and all the electrical equipment are supplied by the battery at a voltage of 12V.

The cables through which the battery voltage is distributed to the various consumers are represented in the wiring diagrams for the various functions and various systems.

There are circuits which are constantly supplied, even with the vehicle stationary and the ignition switched off, as they connected directly to the battery, such as, for example the vehicle brake lights.

Other circuits are supplied when the ignition is switched to the various positions.

#### Starting and recharging:

The starting and recharging circuit is made up of the battery, the starter motor and the alternator.

The battery (12V) is the sealed type which is maintenance-free.

The starter motor consists of a direct current consists of a direct current supplied by the battery and an operation and engagement solenoid.

When the ignition is switched on the voltage coming from the battery supplies the motor windings, creating electro-magnetic forces which cause the rotation of the motor pinion: at the same time the solenoid is energized which operates the pinion engagement mechanism in the flywheel ring gear, thereby causing the rotation of the crankshaft.

The alternator recharges the battery whilst the engine is rotating normally: the alternator shaft, which is rotated directly by the crankshaft through a belt "cuts" the magnetic field generated by the stator winding producing an alternating current; this is transformed into a direct current by a diode rectifier bridge and is sent to recharge the battery.

A voltage regulator incorporated in the alternator allows the current supply to be kept at a constant voltage (around 12V) for all engine speed and load conditions.

### FUNCTIONAL DESCRIPTION

The supply comes from the battery (53), from where there are numerous cables which directly supply several systems including the connector block (36), which is connected directly to the ignition switch (3).

The alternator (139) is connected directly to the starter motor (140) in order to allow the recharging of the battery.

When the ignition key (3) is inserted and turned to the first stage this is the ON position supplying numerous circuits which are defined as "controlled by the ignition key".

The second position is "STARTING UP" where the starter motor is supplied directly with the current no longer reaching all those circuits which absorb directly, thereby ensuring a maximum flow to the actual motor.

In the last analysis we shall evaluate the "PARK" position which supplies the side lights with the ignition key in, which is achieved by turning the ignition key in the opposite direction (pressing on the special button on the ignition switch).

Starting in diesel engines takes place with the assistance of different components compared with petrol engines, such as, for example heater plugs; this means that once the ignition is switched to the ON position it is necessary to wait until the heater plugs warning light (14-S) in the dashboard goes out after which the engine can be started up.

The electronic pre-heating system is composed of:







- an electronic control unit in the engine compartment (205);
- four heater plugs in the engine ante-chambers (206);
- a heater plugs warning light (14-S) in the dashboard.

The aim of the above device is to ensure the following functions:

1. To supply a high pre-heating current from the battery to the heater plugs for a time which varies according to the temperature in the engine compartment, before carrying out the starting.
2. To keep the heater plugs warning light on for a length of time which varies according to the temperature in the engine compartment, then to switch it off so that the engine can be started up.
3. To ensure, for about 20 secs, that the heater plugs (206) still remain supplied if the engine has not been started up within this period the pre-heating electronic control unit (205) has to interrupt the current supply.

**55D.**







**Location of components for starting - Pre-heating system - Recharging**




P3M220N02 P3M220N01



#### Location of components for starting - Pre-heating system - Recharging



P3M221N02 P3M221N01




P3M222N02 P3M222N01

**Wiring for starting - Pre-heating system and heater plugs warning light - Recharging and warning light - Insufficient engine oil pressure warning light - Maximum turbocharging pressure warning light - Rev counter**

#### Key for components

- |   |  |
|---|--|
| 3 Ignition switch                                     | 98 Compressor deactivating control unit (Bitron)     |
| 4 Steering column switch unit                         | 127 Water temperature sensor                         |
| 7 Junction unit                                       | 139 Alternator                                       |
| 12 Connection for dashboard cables with front cables  | 140 Starter motor                                    |
| 14 Instrument panel :                                 | 159 Electric fuel pump deactivating switch           |
| F Rev counter   | 166 Anti-theft electronic control unit               |
| J Insufficient engine oil pressure warning light      | 205 Pre-heating electronic control unit              |
| N Maximum turbocharging pressure warning light        | 206 Heater plugs                                     |
| S Heater plugs warning light                          | 207 Water temperature sensor for K.S.B.              |
| X Battery recharging warning light                    | 208 K.S.B. solenoid valve                            |
| 16 Left dashboard earth                               | 209 Solenoid valve on injection pump                 |
| 33 Connection for front cables                        | 210 Switch signalling maximum turbocharging pressure |
| 36 Connector block                                    | 215 Heated fuel filter relay feed                    |
| 39 Left front earth                                   | 216 20A protective fuse for heated fuel filter       |
| 52 Right rear earth                                   | 217 Heated fuel filter                               |
| 53 Battery  | 218 Injection system relay feed (Turbo Diesel)       |
| 54 Earth for battery                                  | N.D. Connectors                                      |
| 86 Switch signalling insufficient engine oil pressure |  |
| 97 Rpm sensor   |  |





Starting - Pre-heating system and heater plugs warning light - Recharging and warning light - Insufficient engine oil pressure warning light - Maximum turbocharging pressure warning light - Rev counter






### 55D.

Location of components for starting - Pre-heating system - Recharging




P3M224N02

## Chart 5



P3M225N01



P3M225N02

### GENERAL DESCRIPTION

#### Manually or electrically operated sun roof:

The vehicle can be fitted on request with a manually or electrically operated sun roof which allows additional ventilation of the passenger compartment when the weather is hot and a rapid exchange of air.

The moving part of the roof is made up of a plexiglass panel and a sliding interior blind which is in the actual roof panel lining. If the sun roof is manually operated there is a handle located under the roof panel which, when turned clockwise, allows it to slide and at the same time permits the hinged opening of the roof. With electrically operated sun roofs (on more elegant versions) the entire control is electrical by means of a switch in the courtesy light which is above the internal rear view mirror. The entire system is electronically controlled by a control unit which regulates the various functions.

The sun roof can only be operated with the ignition key inserted and the ignition switch in the ON position.

#### Headlamp alignment correcter device:

Some versions offer the possibility of directly adjusting the headlamp alignment according to the different load conditions from the driver's seat. The adjustment device consists of a motor fitted on each headlamp which suitably tilts it so as to lower the luminous beam if the vehicle is particularly laden and raise it when the load is decreased.

The system can only be activated with the dipped beam headlamps/main beam headlamps switched on; otherwise it is completely deactivated.

### FUNCTIONAL DESCRIPTION

A single switch (84) controls all the opening, closing, raising and lowering operations for the sun roof (electrical).

The end of travel position is determined by the switch (81). This switch is located in a control unit (83) in the courtesy light which contains the motor (82) for operating the sun roof. The circuit is controlled by a relay (E6) protected by a 20A fuse in the control unit for the optional equipment (8).

As far as the headlamp alignment correcter is concerned, the adjustment is carried out by two correcters, (68) for the left front light cluster and (69) for the right front light cluster fitted directly on the light clusters. The control (67) is via a potentiometer operated by a knob in the dashboard which can assume four different positions, corresponding to the different positions which the light clusters can assume. The system receives a positive supply of 12V from the ignition switch and is protected by a fuse (5) located in the junction unit (7). The actuator is made up of a correcter to which a potentiometric type position transducer and an electronic control unit is fitted.







# Fault diagnosis

## Accompaniment to illustration table

### 55D.



Punto

Location of sun roof components - Headlamp alignment correcter




P3M226N02 P3M226N01

**Location of electric sun roof components - Headlamp alignment correcter**



P3M227N02 P3M227N01



P3M228N02 P3M228N01

## Wiring for electrically operated sun roof - Headlamp alignment correcter


### Key for components

- |  |   |
|--|---|
| 3 Ignition switch  | 53 Battery  |
| 4 Steering column switch unit:                                   | 54 Earth for battery  |
| F Side lights/dipped headlamps control switch                    | 67 Headlamp alignment device control unit                     |
| G Dipped beam headlamps/main beam headlamps control switch       | 68 Left headlamp alignment correction motor                   |
| H Main beam headlamps switch                                     | 69 Right headlamp alignment correction motor                  |
| 7 Junction unit  | 81 Electrically operated sun roof end of travel switch        |
| 8 Control unit for optional equipment:                           | 82 Electric sun roof operating motor                          |
| E3 Power relay (sun roof)  | 83 Electronic control unit for electrically operated sun roof |
| E4 Dipped beam headlamps/headlamp alignment correcter relay feed | 84 Electrically operated sun roof control switch              |
| 11 Connection for dashboard cables with rear cables              | 121 Connector for electric sun roof cables                    |
| 12 Connection for dashboard cables with front cables             | N.D. Connectors   |
| 16 Left dashboard earth  |   |
| 17 Right dashboard earth   |   |
| 36 Connector block   |   |
| 51 Left rear earth   |   |




Version: E.pack - 1372 turbo

Electrically operated sun roof - Headlamp alignment correcter




## Chart 6

Side lights




P3M231N03

Dipped beam headlamps



P3M231N01

Main beam head-lamps



P3M231N02

## GENERAL DESCRIPTION

**Side lights:**

The side lights are switched on when the special switch on the steering column switch unit is in the first position, with the ignition switched on: this protects the battery charge if the lights are accidentally left on when leaving the vehicle. They are also switched on when the ignition is switched in an anti-clockwise direction, keeping the special button pressed: in the "Parking" position. Together with the side lights the no. plate lights, numerous idoeograms and interior lights for the instrumentation and the controls are also switched on. A warning light in the dashboard signals that the side lights are on. For safety reasons the circuit is protected by two fuses, one for the right front side lights and the left rear ones and the other for the left front side lights and the right rear ones.

**Dipped beam headlamps and main beam headlamps:**

The vehicle has a lamp for the dipped and main beam headlamps which are switched on via the special switch in the steering column switch unit in the position after that for the side lights; under these circumstances it is possible to switch on the dipped headlamps permanently by operating the dipped headlamps/main beam headlamps switch; by gently pulling the steering column switch unit lever towards the steering wheel the "headlamp flasher" or the main beam head-lamps come on. A warning light in the Instrument panel signals that the main beam headlamps are on.







## FUNCTIONAL DESCRIPTION

The fuel system of the various lights takes place through the junction unit (7) located under the dashboard on the driver's side, namely fuses (2 and 3) protect the right and left side lights inside the right front light cluster (23) and the left front light cluster (24) and at the same time they protect the side lights for the respective light clusters (43 and 44) and the number plate lights (41 and 42). All of this takes place when the lever on the steering column switch unit (4) which controls switch F inside is operated. In the second position for this switch the dipped beam headlamps are switched on, protected in the junction unit (7) by fuses (4 and 5) located inside the front light clusters; under these circumstances it is possible to switch on the main beam headlamps via the control lever for switch G inside the steering column switch unit protected by fuses (6 and 7) located in the control unit. It is possible to switch on the main beam headlamps, keeping the other exterior lights off, by operating the headlamp flasher button H on the steering column switch unit.

To check that the side lights or the main beam headlamps have come on there are two warning lights in the instrument panel (14), marked by the letters T and U, respectively (see wiring diagram). There is also a relay E4 in the control unit for the optional equipment located inside the oddments pocket in front of the passenger which allows the dipped beam headlamps to come on even with the main beam headlamps on.

## 55D.







Location of components for side light and warning light - Dipped beam headlamps - Main beam headlamps and warning light - Headlamp flasher - Number plate lights




P3M232N02 P3M232N01



Location of components for side lights and warning light - Dipped beam headlamps - Main beam headlamps and warning light - Headlamp flasher - Number plate lights



P3M233N02 P3M233N01



P3M234N02 P3M234N01


**Wiring for side lights and warning light - Dipped beam headlamps - Main beam headlamps and warning light - Headlamp flasher - Number plate lights**

#### Key for components

- |  |                              |
|--|------------------------------|
| 3 Ignition switch  | 23 Right front light cluster |
| 4 Steering column switch unit:                             | 24 Left front light cluster  |
| F Side lights/dipped headlamps control switch              | 36 Connector block           |
| G Dipped beam headlamps/main beam headlamps control switch | 38 Right front earth         |
| H Main beam headlamps button                               | 39 Left front earth          |
| 7 Junction unit  | 41 Right no. plate light     |
| 8 Control unit for optional equipment:                     | 42 Left no. plate light      |
| E4 Dipped beam headlamps/headlamp alignment relay feed     | 43 Right rear light cluster  |
| 14 Instrument panel :                                      | 44 Left rear light cluster   |
| T Side lights warning light                                | 51 Left rear earth           |
| U Main beam headlamps warning light                        | 52 Right rear earth          |
| 16 Left dashboard earth                                    | 53 Battery                   |
| 17 Right dashboard earth                                   | 54 Earth for battery         |
|  | N.D. Connectors              |

Version: E.pack - 1372 turbo





Side lights and warning light - Dipped beam headlamps - Main beam headlamps and warning light - Headlamp flasher - Number plate lights



P3M235N01


### 55D.

Location of components for side lights and warning light - Dipped beam headlamps - Main beam headlamps and warning light - Headlamp flasher - Number plate lights




P3M236N02 P3M236N01


## Chart 7



P3M237N03



P3M237N01



P3M237N02

### GENERAL DESCRIPTION

#### Electric horns:

The vehicle is equipped with a horn system composed of two different tones; a high tone and a low tone with the two horns coming on at the same time.

The horn is operated by pressing the conventional switch in the centre of the steering wheel. For safety reasons electric horns can be operated at any time even with the ignition switched off.

#### Windscreen wiper - Rearscreen wash/wipe - Electric pump for windscreen and rearscreen washer - Heated rear windscreen and warning light:

The windscreen wiper has two speeds plus an intermittent speed. It is possible to activate the washer pump via the lever on the right of the steering column switch unit and at the same time an automatic wiping cycle is implemented; the system is made up of a motor to which a container which houses the switching circuit made up of a relay and a switch for the automatic return of the blades to the rest position is fixed. It is also possible to operate the pump for the windscreen and rearscreen washer and the rearscreen wiper motor via the same control.

The rear window glass (rebscreen) contains a conducting wire which, when a current passes through it, heats the surfaces with which it comes into contact therefore ensuring rapid demisting. This device is operated by pressing the appropriate switch located in the central panel on the right of the steering column switch unit.

A warning light signals that the device is on.

### FUNCTIONAL DESCRIPTION

The electric horn relay (E2), is supplied by the battery voltage (35) through the fuse (13) located in the junction unit (7). The relay coil is energized through an earth signal coming from the switch (B) located in the centre of the steering wheel integrated with the steering column switch unit (4). In this way the supply is sent by the relay to the two electric horns (27) and (28), right and left, respectively, which are connected to the right front earth (38).

The system for the windscreen wiper, rearscreen wiper, windscreen washer and rearscreen washer is activated by a single lever on the right of the steering column switch unit (4).

The windscreen wiper is made up of a engine (18) which controls the blades either intermittently or continuously, as required: if the lever is moved downwards this operates switch (M) in the centre of the steering column switch unit (4) which engages the intermittent operation of the blades (about 15 strokes per minute).

When, on the other hand, the lever is rotated and switch (M) is in the second position, the speed of the blades is increased (about 35 strokes per minute). Lastly, in the third and last position of the switch the blades are operated at a frequency of 45 strokes per minutes. If the lever is pulled towards the steering wheel this operates the windscreen washer pump, controlled by the motor (19) which is fitted directly the fluid reservoir located inside the front wing on the left hand side.







The rearscreen wiper is controlled by the lever on the right of the steering column switch unit; in effect it has two supplementary switches (I) and (L) where the first controls the rearscreen wiper motor (56) which is activated by rotating this lever and supplying the motor constantly; whilst the second switch operates the rearscreen washer pump by means of the motor (19), only in this case in addition to sending the fluid to the rearscreen it operates the blade at the same time until the lever is released.

The relay feed for the heated rear windscreen (E3) located in the junction unit (7) is controlled by the ignition therefore the ignition has to be switched ON in order to supply it; when this is the case the relay coil is supplied and consequently also the line which, protected by the fuse (11) for the control unit, reaches the heated rear windscreen (55) and its resistances. The same supply signal for the rearscreen is sent to the switch control unit (15) where there is a switch (A) which controls the warning light marked with the letter (B) integrated with the relevant switch.









## 55D.

Location of components for windscreen wiper - Rearscreen wash/wipe - Windscreen and rear window washer pump - Electric horns - Heated rear windscreen and warning light




P3M238N02 P3M238N01

Location of components for windscreen wiper - Rearscreen wash/wipe - Windscreen and rear window washer pump - Electric horns - Heated rear windscreen and warning light



P3M239N02 P3M239N01



P3M240N02 P3M240N01


**Wiring for windscreen wiper - Rearscreen wash/wipe - Windscreen and rear window washer pump - Electric horns - Heated rear windscreen and warning light**

#### Key for components

- |  |   |
|--|---|
| 3 Ignition switch  | 15 Switch control unit :  |
| 4 Steering column switch unit:                                       | A Heated rear windscreen control switch                         |
| B Horn control   | B Heated rear windscreen warning light                          |
| I Rearscreen wiper control switch                                    | 16 Left dashboard earth   |
| L Control for windscreen washer/rearscreen wiper and headlamp washer | 18 Windscreen wiper motor with intermittent device incorporated |
| M Windscreen wiper control switch                                    | 19 Electric windscreen washer pump/rearscreen washer            |
| 7 Junction unit :  | 27 Right electric horn  |
| E1 Ignition discharge relay  | 28 Left electric horn   |
| E2 Electric horn relay feed  | 36 Connector block  |
| E3 Heated rear windscreen relay feed                                 | 38 Right front earth  |
| 11 Connection for dashboard cables with rear cables                  | 39 Left front earth   |
|  | 50 Connection for rear cables                                   |
|  | 51 Left rear earth  |
|  | 53 Battery  |
|  | 54 Earth for battery  |
|  | 55 Heated rear windscreen                                       |
|  | 56 Rearscreen wiper motor                                       |
|  | N.D. Connectors   |

Version: E.pack - 1372 turbo






Windscreen wiper - Rearscreen wash/wipe - Windscreen and rear window washer pump - Electric horns - Heated rear windscreen and warning light





## 55D.


Location of components for windscreen wiper - Rearscreen wash/wipe - Windscreen and rear window washer pump - Electric horns - Heated rear windscreen and warning light




P3M242N02 P3M242NU1



## Chart 8



P3M243N02



P3M243N01

**GENERAL DESCRIPTION****Fog lights and rear fog lamps:**

The vehicle is equipped with special halogen type fog lights and very bright rear lights for all situations where visibility is poor. This entire system ensures the maximum possible visibility in all circumstances.

The fog lights are switched on via a special switch in the light switch panel where the switch for the rear fog lamps is also located.

The fog lights can be switched on with the side lights on, whilst the rear fog lamps can only be switched on if the dipped headlamps are on, or with the fog lights on. Two warning lights on the actual switches signal that the fog lights or the rear fog lamps are on. Each of the two circuits is protected by a special fuse.

**Handbrake applied:**

The main function of the lever on the central tunnel is to ensure that the vehicle is kept stationary whilst parked on very steep inclines, but this lever can also be used for other purposes: e.g. when moving off on an incline, etc. In order to engage the handbrake or parking brake, it is necessary to pull the lever upwards to the end of travel position and to release it it must be pulled upwards and the button located at the top must be pressed in and the lever lowered. Usually it acts directly on the rear wheels of the vehicle. There is a red coloured warning light with the letter P on it in the dashboard which comes on when the handbrake is applied and lights up each time the switch is closed.

**FUNCTIONAL DESCRIPTION**







The circuit for the fog lights is controlled by the appropriate relay (E5) located in the control unit for the optional equipment. If the switch (G) in the switch unit (15) is operated this sends an earth which energizes the relay coil thereby closing the circuit which sends a supply to the right and left fog lights (25) and (26), respectively. The switch (G) is lit up e (G) when the side lights are switched on. The circuit is protected by the fuse (2) located in the control unit for the optional equipment (8). The relay feed sends a signal to the switch unit to light up the appropriate warning light (F) in the switch which indicates that the fog lights are on. This all takes place if the side lights are on.

As far as the rear fog lamps are concerned the circuit is controlled by the relay (E6) located in the control unit for the optional equipment (8). Through a special switch (E) in the switch unit, with the dipped beam headlamps on, a supply and earth is sent to the relay coil thereby closing the circuit which sends the supply to the right (43) and left (44) rear fog lamps. The circuit is protected by the fuse (8) in the junction unit (7). At the same time a signal is sent to the warning light (D) in the switch in the control unit (15) which indicates that the rear fog lamps are on. The rear fog lamps only work if the dipped headlamps are on or if the fog lights are on.

The handbrake warning light, is in the instrument panel (14) marked with the letter (I) and is protected by the fuse (1) in the junction unit (7) and is controlled by a switch (40) located under the handbrake lever.





## 55D.

Location of components for fog lights and warning light - Rear fog lamps and warning light - Hand-brake warning light




P3M244N02 P3M244N01

**Location of components for fog lights and warning light - Rear fog lamps and warning light - Hand-brake warning light**



P3M246N02



P3M246N02 P3M246N01


# **Wiring for fog lights and warning light - Rear fog lamps and warning light - Handbrake warning light**

## **Key for components**

- |  |  |
|--|--|
| 3 Ignition switch                                    | 16 Left dashboard earth                |
| 4 Steering column switch unit:                       | 17 Right dashboard earth               |
| F Side lights/dipped beam headlamps control switch   | 25 Right fog light                     |
| G Dipped beam/main beam headlamps control switch     | 26 Left fog light                      |
| H Main beam headlamps button                         | 36 Connector block                     |
| 7 Junction unit                                      | 38 Right front earth                   |
| 8 Control unit for optional equipment :              | 39 Left front earth                    |
| E5 Fog lights relay                                  | 40 Switch signalling handbrake applied |
| E6 Relay feef for rear fog lamps with fog lights on  | 43 Right rear light cluster            |
| 11 Connection for dashboard cables with rear cables  | 44 Left rear light cluster             |
| 12 Connection for dashboard cables with front cables | 51 Left rear earth                     |
| 14 Instrument panel :                                | 52 Right rear earth                    |
| I Handbrake warning light                            | 53 Battery                             |
| 15 Switch unit:                                      | 54 Earth for battery                   |
| D Rear fog lamps warning light                       | N.D. Connectors                        |
| E Rear fog lamps control switch                      |  |
| F Fog lights warning light                           |  |
| G Fog lights control switch                          |  |


Version: E.pack - 1372 turbo

Fog lights and warning light - Rear fog lamps and warning light - Handbrake warning light







## Chart 9



P3M249N03



P3M249N01



P3M249N02

## GENERAL DESCRIPTION

**Cigar lighter:**

There is an ashtray in the centre of the dashboard for the occupants of the vehicle. The resistance for the cigar lighter is located in the ashtray; the cigar lighter is switched on by pressing it in and then it pops out automatically after several seconds and is ready to use. This standard type socket can also be used for connecting other instruments of equipment (operating at 12 V). The socket is supplied even when the ignition is in the PARKING position or with the instruments switched off.

**Engine cooling:**

An electric fan makes it possible to increase the dissipation of the heat by the radiator and the engine coolant. A thermal switch detects when the temperature of the coolant is too high and operates the electric fan: the contact opens at between 90 and 94 degrees centigrade and closes at between 85 and 89 degrees centigrade.







## FUNCTIONAL DESCRIPTION

The socket for the cigar lighter (13) resistance is supplied directly by the battery voltage via the fuse (10) located in the junction unit (7) which protects the circuit. The light for the cigar lighter comes on with the side lights on: in effect, it is supplied when the lever on the steering column switch unit (4) which controls switch F is operated. The voltage coming from the relay (E1) in the junction unit passes through the fuse (2).

The electric fan (64) is supplied at the battery voltage through the fuse (12) inside the junction unit. The relay (E1) which controls the electric fan is controlled by the ignition and is energized by an earth signal coming from the thermal contact (65) which closes when the temperature of the coolant reaches 92 degrees centigrade; in this way the switch (65) sends an earth to the motor which operates the electric fan. When the temperature goes down below 87 degrees centigrade the contact opens, the relay is de-energized and the fan switches off.







### 55D.

Location of components for engine cooling - Car interior ventilation - Water temperature gauge - Cigar lighter




P3M250N02 P3M250N01

Location of components for engine cooling - Car interior ventilation - Water temperature gauge - Cigar lighter



P3M251N02 P3M251N01




P3M252N02 P3M252N01

# **Wiring for engine cooling - Car interior ventilation - Water temperature gauge - Cigar lighter**

## **Key for components**


- |  |                                      |
|--|--------------------------------------|
| 3 Ignition switch                                    | 36 Connector block                   |
| 4 Steering column switch unit:                       | 37 Heater controls                   |
| F Side lights/dipped beam headlamps control switch   | 38 Right front earth                 |
| G Dipped/main beam headlamps control switch          | 39 Left front earth                  |
| H Main beam headlamps button                         | 53 Battery                           |
| 7 Junction unit :                                    | 54 Earth for battery                 |
| E1 Ignition discharge relay                          | 64 Engine cooling fan                |
| 8 Control unit for optional equipment                | 65 Engine cooling fan thermal switch |
| 12 Connection for dashboard cables with front cables | 66 Engine coolant temperature sensor |
| 13 Cigar lighter                                     | N.D. Connectors                      |
| 14 Instrument panel :                                |                                      |
| C Water temperature gauge                            |                                      |
| C1 Coolant temperature overheating warning light     |                                      |
| 16 Left dashboard earth                              |                                      |
| 17 Right dashboard earth                             |                                      |
| 33 Connection for front cables                       |                                      |
| 34 Connection for front cables                       |                                      |

**Engine cooling - Car interior ventilation - Water temperature gauge - Cigar lighter**





## Chart 10



P3M255N01

**GENERAL DESCRIPTION****Anti-lock brakes A.B.S. (Bosch 2SH)**

The vehicle is equipped with anti-lock brakes (A.B.S.). This system regulates the braking pressure transmitted to the wheels preventing loss of adhesion for all tyre conditions and road surfaces.

The system has been designed to be integrated with and not to replace the normal mechanical braking system, thereby guaranteeing effective safety in the case of problems: it comes into operation using the same fluid as the conventional mechanical circuit braking system. Four sensors, located on the four wheels, send the electronic control unit signals concerning the speed of each wheel, thereby recording situations where the wheels lock, slip or lose adhesion. In these situations the control unit operates the solenoid valves which modulate the pressure in the hydraulic circuit, preventing the wheels from locking and ensuring that the adhesion is maintained, which allows the minimum possible braking distance, without losing control of the steering.

The A.B.S. also includes an autodiagnostic system which constantly checks all the system components and parameters: in the case of failures or malfunctions, the system automatically cuts out, allowing the conventional, mechanical servo-assisted system to operate: this situation is signalled to the driver by means of a special warning light in the instrument panel.







**FUNCTIONAL DESCRIPTION**

The system is made up of four sensors located on the four wheels, namely on the left front wheel (115), the right front wheel (116), the left rear wheel (117) and lastly the right rear wheel (118); they read the speed of the wheels and are operated by an electronic control unit (113) where, in addition to the electronic control module there are also two relays, one for controlling the pump and another safety relay.

The module is connected, inside the control unit, to the adjustment solenoid valves, whilst on the outside it is connected to the four sensors which signal the speed of the vehicle and with the brake switch (20) which sends a go ahead signal: in effect the operation of the system is excluded when the brake pedal is not pressed. When the control unit detects problems through the autodiagnostic function by means of the diagnostic socket (114), it sends a signal to the instrument panel (14) which lights up the A.B.S. failure warning light which has the letter (M) on it: this signal depends on the malfunction of the electronic module or the operation of the hydraulic section. The circuit is protected by a 10A fuse (31).







## 55D.

Location of components for anti-lock brakes (A.B.S. 2SH) and failure warning light




P3M256N02 P3M256N01

**Location of components for anti-lock brakes (A.B.S. 2SH) and failure warning light**



P3M257N02 P3M25/N01



P3M258N02 P3M258N01


## Wiring for anti-lock brakes (A.B.S. 2SH) and failure warning light

### Key for components

- |   |   |
|---|---|
| 3 Ignition switch   | 113 Electronic control unit for anti-lock brakes (A.B.S.) |
| 4 Steering column switch unit   | 114 Diagnostic socket for anti-lock braking system        |
| 7 Junction unit   | 115 Sensor on left front wheel (A.B.S.)                   |
| 12 Connection for dashboard cables with front cables                      | 116 Sensor on right front wheel (A.B.S.)                  |
| 14 Instrument panel :<br>M Anti-lock braking system failure warning light | 117 Sensor on left rear wheel (A.B.S.)                    |
| 20 Brake lights switch  | 118 Sensor on right rear wheel (A.B.S.)                   |
| 31 10A protective fuse for anti-lock brakes                               | N.D. Connectors   |
| 32 Connection for anti-lock brakes cables                                 |   |
| 35 Connection between front cables and anti-lock brakes cables            |   |
| 36 Connector block  |   |
| 39 Left front earth   |   |
| 53 Battery  |   |
| 54 Earth for battery  |   |

Version: F.pack - E.pack - 1372 turbo





Anti-lock brakes (A.B.S. 2SH) and failure warning light






## 55D.

Location of components for anti-lock brakes (A.B.S. 2SH) and failure warning light



P3M260N02

**Chart 11**

P3M261N01

**GENERAL DESCRIPTION****Electric front windows:**

The vehicle may be equipped with electric front windows. The type of operation is automatic, controlled by a control unit which operates in accordance with the following logic: when one of the two buttons is pressed and kept pressed the window opens or closes normally until the button is released.

However, in the case of a quick impulse the motor is operated and only stops automatically in the end of travel position (window completely open or closed).

Lastly there is the case of the button being pressed for less than 50 ms. which is considered by the control unit as an accidental impact and nothing happens.

Both the windows are "controlled by the ignition", but the control unit allows the operation of the left front window even if the ignition is switched off if that door is open. The electrical mechanism which operates the right front window is, however, conventional: when the button is pressed the window goes up or down; there are three control switches: two on the left door and one on the right.

**FUNCTIONAL DESCRIPTION**

The electrical system for the electric windows is made up of an electronic control unit (E2) fitted on the control unit for the optional equipment (8) which allows the operation of the driver's side window both conventionally and automatically.

With the ignition switch (3) in the ON position, if the driver's side electric window electric window control button (72) is pressed, the window operates automatically, i.e. the window closes or opens fully even without keeping this button pressed.







The window for the passenger side door can only be operated conventionally by pressing the appropriate control buttons in the driver's side control panel (73) and the passenger side control button (74).

There is a double switch inside the control panel which sends an earth to the control unit and consequently to the left motor (70) or right motor (71) from the section where the contact is closed, thereby determining the direction of rotation of the actual motor.

The circuit is protected by a fuse (10) in the junction unit (7).







### 55D.

Location of components for electric front windows




P3M262N02

**Location of components for electric front windows**



P3M263N02 P3M263N01





P3M264N02 P3M264N01

## Wiring for electric front windows


### Key for components

- |   |   |
|---|---|
| 1 Right front courtesy light button signalling door ajar                              | 70 Driver's side front electric window motor                |
| 2 Left front courtesy light button signalling door ajar                               | 71 Passenger side front electric window motor               |
| 3 Ignition switch   | 72 Left front electric window driver's side control panel   |
| 4 Steering column switch unit   | 73 Right front electric window driver's side control panel  |
| 7 Junction unit   | 74 Right front electric window passenger side control panel |
| 8 Control unit for optional equipment :<br>E2 Control unit for electric front windows | N.D. Connectors   |
| 9 Connection for passenger side front door dashboard cables                           |   |
| 10 Connection for driver's side front door dashboard cables                           |   |
| 16 Left dashboard earth   |   |
| 17 Right dashboard earth  |   |
| 36 Connector block  |   |
| 53 Battery  |   |
| 54 Earth for battery  |   |



Version: E.pack - 1372 turbo

Electric front windows



P3M265N01

## Chart 12

## Central locking



P3M267N01

## GENERAL DESCRIPTION

**Central locking:**

The central locking device is made up of an electronic control unit which controls and operates the door locks; each of them comprises a locking/unlocking geared motor, a control switch (connected only to the electrical circuit for the front doors) and a switch signalling that the door is ajar.

The control unit logic does not allow the locking/unlocking if there is a signal that one of the doors is open.

When all four doors are properly shut the geared motors are able to operate, all four at the same time, acting on the control switches, from inside through the knobs or from outside with the key.

For safety reasons the switches for the rear doors are mechanical only (and only close the appropriate door) and do not come into operation for the electrical locking / unlocking.

## FUNCTIONAL DESCRIPTION

The device is made up of four geared motors (75 - 76 - 79 - 80) in the locks of the four doors.

The system is controlled by an electronic unit (E1) fitted on the control unit for the optional equipment (8).







When a locking operation is carried out, the electronic unit (E1) locks all the locks simultaneously via the front locks (75 - 76). When an unlocking operation is carried out, the locks for the four doors are unlocked.

The electronic control unit (E1) is equipped with an electronic safety circuit which cuts off the supply to the geared motors 15 - 35 secs after a locking or unlocking command has been given. This is to prevent the geared motors from being constantly supplied and burning out if the relay feeds become stuck. From the moment the integrated circuit detects several consecutive manoeuvres, at least 4 - 10 in the time interval (150 - 250 ms.), the system intervenes activating the manoeuvre restricter. The latter remains inhibited in the release position for 90 to 150 secs.

There is a warning light in the instrument panel (14) marked with the letter R signalling that a door is ajar which remains on each time one of the four doors is accidentally left open (with the ignition switched on) and the warning light is protected by a fuse (1) in the junction unit (7).







## 55D.

Location of components for central locking - Warning light signalling doors ajar




P3M268N02

Location of components for central locking - Warning light signalling doors ajar



P3M269N02 P3M269N01



P3M270N02 P3M270N01

## Wiring for central locking - Warning light signalling doors ajar


### Key for components

- |  |  |
|--|--|
| 3 Ignition switch  | 75 Right front central locking geared motor signalling door ajar             |
| 4 Steering column switch unit  | 76 Left front central locking geared motor signalling door ajar              |
| 7 Junction unit  | 77 Connection for left rear door rear cables                                 |
| 8 Control unit for optional equipment :<br>E1 Control unit for central locking | 78 Connection for right rear door rear cables                                |
| 9 Connection for passenger side front door dashboard cables                    | 79 Left driver's side rear central locking geared motor signalling door ajar |
| 10 Connection for driver's side front door dashboard cables                    | 80 Right side rear central locking geared motor signalling door ajar         |
| 11 Connection between dashboard cables and rear cables                         | N.D. Connectors  |
| 14 Instrument panel :<br>R Warning light signalling doors ajar                 |  |
| 16 Left dashboard earth  |  |
| 17 Right dashboard earth   |  |
| 36 Connector block   |  |
| 49 Central locking remote control receiver                                     |  |
| 51 Left rear earth   |  |
| 52 Right rear earth  |  |
| 53 Battery   |  |
| 54 Earth for battery   |  |









Version: E.pack - 1372 turbo

Central locking - Warning light signalling doors ajar




## 55D.

Location of components for central locking - Warning light signalling doors ajar




P3M272N02 P3M2/2N01


## Chart 13



P3M273N03



P3M273N01



P3M273N02

### GENERAL DESCRIPTION

#### Direction indicators and hazard warning lights:

The right or left direction indicators are switched on by raising or lowering the special lever on the left of the steering column switch unit; the hazard warning lights (left and right direction indicators operating at the same time) are switched on by means of the special switch, behind the steering wheel close to the instrument panel.

The direction indicators only work with the ignition switch in the ON position, the hazard warning lights, on the other hand, are supplied directly by the battery, for safety reasons.

Two warning lights in the panel, which are also intermittent, signal that the left or right indicators are on.

As far as the hazard warning lights are concerned the actual switch lights up.

#### Reversing lights:

These come on automatically, by means of a special switch on the gearbox. The lights only come on with the ignition switch in the ON position, independently of the other lights.

#### Brake lights and problem warning light (check):

The brake lights (stop lights) are activated each time the brake pedal is pressed. The lights come on automatically via the special switch on the brake pedal; they are activated in all conditions even with the ignition switched off. Their correct operation is checked by the "CHECK - PANEL" which signals any malfunction of the circuit by the warning light coming on.

### FUNCTIONAL DESCRIPTION

Operating the steering column switch unit (4) lever which controls a switch (A) positioned on it, causes either the right indicators (23), (5) and (43) or the left indicators (24), (6) and (44) to come on depending on which side the switch is closed from. There is only one warning light (H) located in the instrument panel (14) which comes on each time the left indicator or the right indicator operates.

There is a switch (C) on the steering column switch unit (4) which controls the hazard warning lights supplying the right and left lights at the same time and the warning light in the switch (E). There is a timer (D) located in the steering column switch unit for both lights.







As far as the circuit for the reversing lights is concerned it is supplied with the ignition on through the fuse (1) in the junction unit (7). When reverse gear is engaged the switch (21) closes and the lights in the right (43) and left (44) light clusters come on.

The circuit for the brake lights is supplied directly by the battery (53) through the fuse (1) in the junction unit (7). The brake lights switch (20) is closed when the pedal is not pressed and signals the continuity of the circuit to the Check - Panel control unit (A). When the brake pedal is pressed the brake lights in the right (43) and left (44) light clusters are supplied.

Signals leave these circuits for the control unit which checks the condition of the lights; if there is a problem the warning light (A1) in the panel (14) comes on.

## 55D.







Location of components for control-system - Direction indicators and warning light - Hazard warning lights and warning light - Reversing lights - Brake lights and warning light (check)



P3M274N02 P3M2/4NU1




Location of components for control-system - Direction indicators and warning light - Hazard warning lights and warning light - Reversing lights - Braking lights and warning light (check)



P3M275N02 P3M2/5N01





P3M276N02 P3M276N01


**Wiring for control-system - Direction indicators and warning light - Hazard warning lights and warning light - Reversing lights - Brake lights and warning light (check)**

#### Key for components

- |  |                                    |
|--|------------------------------------|
| 3 Ignition switch                                  | 17 Right dashboard earth           |
| 4 Steering column switch unit:                     | 20 Brake lights control switch     |
| A Direction indicators control switch              | 21 Reversing lights control switch |
| C Hazard warning lights switch                     | 23 Right front light cluster       |
| D Direction indicators/hazard warning lights timer | 24 Left front light cluster        |
| E Hazard warning lights warning light              | 36 Connector block                 |
| 5 Right front side direction indicator             | 38 Right front earth               |
| 6 Left front side direction indicator              | 39 Left front earth                |
| 7 Junction unit                                    | 43 Right rear light cluster        |
| 8 Control unit for optional equipment              | 44 Left rear light cluster         |
| 14 Instrument panel :                              | 51 Left rear earth                 |
| A Check-panel module                               | 52 Right rear earth                |
| A1 Warning light signalling brake lights failure   | 53 Battery                         |
| H Direction indicators warning light               | 54 Earth for battery               |
| 16 Left dashboard earth                            | N.D. Connectors                    |

Version: E.pack - 1372 turbo


Control-system - Direction indicators and warning light - Hazard warning lights and warning light - Reversing lights - Brake lights and warning light (check)



\* Variant connections for the 1372 turbo version

P3M277N01

## Chart 14



P3M279N01

### GENERAL DESCRIPTION

#### AIR - BAG:

The Air - Bag is a passive safety device made up of one or two cushions which inflate automatically in the case of a frontal impact positioning themselves between the bodies of the occupants of the front seats of the vehicle and the front section of the passenger compartment.

The system is made up of the following components:

- an electronic control unit which contains an electronic circuit with two deceleration sensors; having assessed the impact situation it implements the intervention strategies and checks and memorizes any problems. There is also a driver's side and passenger side AIR-BAG module, a warning light which signals any problems and a diagnostic socket for connection to the Fiat / Lancia Tester.

- The electronic control unit equipped with suitably calibrated deceleration sensors, detects the impact condition and sets off a chemical reaction which produces nitrogen by means of two electrical detonators. The gas inflates the synthetic fibre cushions housed in the centre of the steering wheel and in a casing in the dashboard in front of the front passenger, respectively.

The system intervenes when the deceleration of the vehicle corresponds to that for a frontal impact at a speed of about 20 - 25 kph against a fixed barrier.

The electronic control unit is located in the central tray for the vehicle and receives a 12V supply when the ignition switch is in the ON position.

### FUNCTIONAL DESCRIPTION

The entire circuit is controlled by the ignition and is protected by the fuse (1) in the junction unit (7).

The circuit includes two cushions, one located on the driver's side (in the middle of the steering wheel) (108) and one in front of the passenger (11); there is also a control unit (110) which, whilst the vehicle is driving, carries out a constant diagnosis of the system, checking the continuity of the circuits and the components.

When a fault or malfunction is detected in the system, the type of problem is memorized and the Air-Bag warning light (Y) in the instrument panel (14) comes on thereby alerting the driver to the problem.

Lastly, there is a connection which acts as a diagnostic socket (112) which when connected to the Fiat / Lancia Tester detects any problems in the system.







# Fault diagnosis

## Accompaniment to illustration table

### 55D.






Punto

Location of AIR-BAG components and warning light




P3M280N02 P3M280N01

**Location of AIR-BAG components and warning light**



P3M281N02 P3M281N01





P3M282N02 P3M282N01


## Wiring for AIR-BAG and warning light

### Key for components

- |  |                                     |
|--|-------------------------------------|
| 3 Ignition switch  | 108 AIR-BAG charge (driver's side)  |
| 4 Steering column switch unit                                    | 109 Connection for AIR-BAG cables   |
| 7 Junction unit  | 110 AIR-BAG electronic control unit |
| 12 Connection between dashboard cables and front cables          | 111 AIR-BAG charge (passenger side) |
| 14 Instrument panel :<br>Y AIR-BAG circuit failure warning light | 112 Diagnostic socket for AIR-BAG   |
| 36 Connector block   | 165 Connection for AIR-BAG cables   |
| 39 Left front earth  | N.D. Connectors                     |
| 53 Battery   |                                     |
| 54 Earth for battery   |                                     |


Version: All

# AIR-BAG and warning light




## Chart 15

Car interior lighting




P3M285N03

Ideogram lights



P3M285N01

Preparation for radio



P3M285N02

## GENERAL DESCRIPTION

The numerous lighting points ensure that the passenger compartment is well lit in all conditions and that the controls can be easily read.

The wiring diagram for this fault diagnosis includes:

- the courtesy lights, i.e. courtesy light on the ceiling and the luggage compartment light operated when one or more doors or the tailgate is opened.
- the ideogram lights, or all those lights which light up the ideograms, the controls and the switches with the side lights switched on.
- the supply of the digital clock in the ceiling.
- the preparation for the radio with the possibility of connection to up to six speakers.

The aerial is located on the roof in an opening by the courtesy light in the ceiling and it is connected to the radio by a cable. The circuit for the radio is always supplied therefore the radio can be switched on at any time, even with the ignition switched off.

## FUNCTIONAL DESCRIPTION

With the side lights on, the following controls and ideograms are lit up:

The ideograms on the steering column switch unit (4) and on the air vents; the heater or air conditioner controls, the ashtray (13), the switches for the fog lights, rear fog lamps and heated rear windscreen (15) and the instrument panel (14).

When either of the front doors is opened the courtesy light (45) comes on and remains on until the door is closed. The courtesy light in the ceiling can also be operated manually, through a special switch.

In the same assembly there is also an adjustable map reading light, connected, by means of a fuse (10) in the junction unit (7), to the battery, making it possible to read without disturbing the driver.

There is a special courtesy light (46) for the luggage compartment which comes on when the tailgate is opened.

The vehicle is available, on request, with preparation for a radio. The electrical equipment for this version is made up of a radio (mod.DC 710/64S PHILIPS) with a removable front section, with four cables, two connected to the left speaker (59) and two connected to the right speaker (58), both with a 165 mm double cone in the front doors.

The same cables go to the dashboard and are connected to two tweeters one in the left section of the dashboard (62) and one in the right section (63).







There are also another four cables going from the radio, two connected to the left speaker (61) and two to the right speaker (60), both in the rear section of the rear parcel shelf. These speakers are 100 mm double cone types.

The speakers are connected by means of connector (B) in the rear part of the radio.

There is another connector in the rear part and connector (A) used for connecting the battery supply through fuse (10). This connector also connects the radio in the case of the so-called "heavy" version by means of two cables to the controls on the steering wheel; these controls operate the volume (min. - max.) (N,O), the band (Q) and the tuning (P) or programme selection.







**55D.**

Location of components for radio preparation - Car interior lighting - Ideogram lights




P3M286N02 P3M286N01

**Location of components for radio preparation - Car interior lighting - Ideogram lights**



P3M287N02 P3M28/N01





P3M288N02 P3M288N01

## Wiring for radio preparation - Car interior lighting - Ideogram lights

### Key for components

- 1 Right front courtesy light button and door ajar signal
- 2 Left front courtesy light button and door ajar signal
- 3 Ignition switch
- 4 Steering column switch unit:
  - F Side lights/dipped headlamps control switch
  - G Dipped beam headlamps/main beam headlamps control switch
  - H Main beam headlamps control
  - N Volume increase control (on steering wheel)
  - O Volume decrease control (on steering wheel)
  - P Programme selection control (on steering wheel)
  - Q Band section control (on steering wheel)
- 7 Junction unit
- 8 Control unit for optional equipment
- 9 Connection for passenger side front door dashboard cables
- 10 Connection for driver's side front door dashboard cables
- 11 Connection between dashboard cables and rear cables
- 13 Cigar lighter
- 14 Instrument panel :
- T1 Ideogram light bulbs

- 15 Switch unit :
  - C Switch unit ideogram light
- 16 Left dashboard earth
- 17 Right dashboard earth
- 36 Connector block
- 45 Courtesy lights
- 46 Luggage compartment light bulb
- 48 Digital clock
- 50 Connection for rear cables
- 51 Left rear earth
- 53 Battery
- 54 Earth for battery
- 57 Radio
- 58 Speaker in right front door
- 59 Speaker in left front door
- 60 Right rear speaker
- 61 Left rear speaker
- 62 Left front speaker
- 63 Right front speaker
- 211 Switch for luggage compartment light and anti-theft device
- N.D. Connectors

## Preparation for radio - Car interior lighting - Ideogram lights

