

PUNTO eMANUAL


Electrical Equipment

Title	Page
Views	1 ➡

55.


FRONT/REAR VIEWS OF SWITCH PANEL ('96 range)

Front view of switch panel




P3M14XL01

Rear view of switch panel



P3M14XL02

Wiring diagram of internal connections of instrument panel



P3M14XL03

15


- A) - Heated rear window switch
- B) - Heated rear window warning light
- C) - Switch control symbol illumination
- D) - Rear fog lamps warning light
- E) - Rear fog lights switch
- F) - Front fog lamps warning light
- G) - Front fog lights switch

15A

- A) - LED indicating fault in switching on of anti-theft device


FRONT/REAR VIEWS OF SWITCH PANEL
('97 range)

Front view of switch panel




P3M15XL01

Rear view of switch panel



P3M15XL02

Wiring diagram of internal connections of switch panel



P3M15XL03

- 15**
- A) - Heated rear window switch
 - B) - Heated rear window warning light
 - C) - Switch control symbol illumination
 - D) - Rear fog lamps warning light
 - E) - Rear fog lamps switch
 - F) - Front fog lamps warning light
 - G) - Front fog lamps switch
 - N) - Air conditioner switch
 - O) - Air conditioner on warning light
 - P) - Alarm on warning light